STEP 1

ENSURE UNIT GASKET IS APPLIED PROPERLY. MOUNT CONVERSION COLLAR TO UNIT AS SHOWN USING THE PROVIDED HARDWARE. COMPRESS THE UNIT GASKET TO HALF OF ITS THICKNESS.

STEP 2


APPLY CONVERSION COLLAR GASKET AS SHOWN.


NOTE: UNIT HIDDEN FOR CLARITY


STEP 3

FOR ADDITIONAL CAPACITY SEE OPTIONAL CUTOUT, IQ352950 MOUNT UNIT AND CONVERSION COLLAR TO ENCLOSURE AS SHOWN USING PROVIDED HARDWARE.

COMPRESS THE CONVERSION COLLAR GASKET TO HALF OF ITS THICKNESS.







9/16/2021 1:5

NAT 9/16/2021

DATE

APP

DATE

CN# NAT

CHG

UNLESS OTHERWISE SPECIFIED TOLERANCES ±.060 ±.030 ±.015 FRACTIONAL ±1/16 ANGULAR ±1/2° DO NOT SCALE DRAWING DIMENSIONS ARE INCHES

.XX .XXX

ICE QUBE, INC. THIS IS A PROPRIETARY DOCUMENT. DO NOT REPRODUCE OR DISCLOSE WITHOUT THE EXPRESS WRITTEN PERMISSION OF ICE QUBE. INC. IQ20-2400VXS TO IQ1-2-3000EV/ECO CONVERSION COLLAR INSTRUCTIONS

IQ352890

QD-ENG-55 REV 0

Α SHEET 1 of 1